

**The drive screw** is used for manual switching on and off of the circuit breaker mechanism from outside the flameproof enclosure of the transformer station, by means of an indirect manual drive. The screw is installed in the apparatus compartment of the lower voltage side of the transformer station.

The change of position of the contacts of the Q2 switch takes place after rotating the screw shaft of the mechanism drive, which changes the switch setting through the lever.

