

 <p>ISO 9001 OBAC/002/SZJ/23</p>	<p><b>P.H.P.U.</b>  <b>IZOL PLAST</b>          Sp. z o.o.          44-362 Rogów          ul. Raciborska 79          tel./fax 32-4512444,          32-4512010  <a href="http://www.izol-plast.rogow.pl">www.izol-plast.rogow.pl</a></p>	<p><b>INDEX CARD</b></p>
		<p><b>Disconnecter / disconnector drive cover</b></p>

**Disconnecter / disconnector operating cover** is used in flameproof transformer stations in order to protect the disconnector or disconnector operating sleeve against mechanical damage.

